ID3 - Series: C



Waterblast: Heat exchanger tube cleaning, ultra high-pressure

> waterjet cutting and hydro demolition (cutting and demolition of armoured concrete, pipelines, paper or

steel)

Hydraulics: Pressure test equipment (valves, tooling and control

panels), hydraulic tools (instrumentation packages for

gauges, control of service equipment, hydraulic jacks,

hydraulic tools)



Technical Information

Inner Core: Polyoxymethylene (POM)

Pressure Support: 6 layers of high-tensile steel wire

Outer Cover: Polyamide (PA)

Color: Blue

Temperature: -30°C to +60°C [-22°F to 140°F]

ØID	Ø OD	Working Pressure		Burst Pressure	Bend Radius	Weight	Insert ID
			(SF 2,5:1)				
3,0 mm	9,1 mm		2.800 bar	7.000 bar	150 mm	0,222 kg/m	1,8 mm
0,12 inch	0,36 inch		40.600 psi	101.500 psi	5,91 inch	0,149 lbs/ft	0,07 inch

			Dimensions (mm)				Sleeve	
Part no.	Thread	Material		Α	В	С	암	5 .6676
Sleeve								
10360102	-	Steel		15,3	32,5	-	-	
								4

Part no.	Thread	Material	Nut	Dime A	nsions (mm)	암	Insert
HP fitting								
40360204C	I/4"x28UNF LH	Stainless steel	-	1,8	68	14	-	- C -
40360224C	3/8"x24UNF LH	Stainless steel	-	1,8	76	20	-	4 B B



ID3 - Series: C

Part no.	Size (mm)	Material	Crimp ring	Hose protection
Hose protec	tion without spiral			
1.901621	ID Ø16, OD Ø21	PVC	1002224	
1.902026	ID Ø20, OD Ø26	PVC	-	
				- The state of the

Part no.	Mesh length (mm)	Overall length (mm)	Breaking strength (kN)	Suitable for SPIR STAR® hose outer diameter (mm)	Hose securing grip
Hose secu	ring grip shor	t version			
9034400	600,00	740,00	6,60	6-10	

		Accessories combinations			
Without hose protection					
Description		Bend restrictor	Crimp ring	Securing grips	
Securing grip		-	-	9034400	
Hose protection without spiral					
Description	Protection hose	Bend restrictor	Crimp ring	Securing grips	
Protection hose	1.901621	-	1002224	-	
with securing grip	1.902026	-	-	9034400	

Production related variations of the burst pressure of up to 5 % are possible. Other colors upon request.

The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center.

The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly may be less.

We reserve our rights for technical changes without notice. Subject to printing errors.

^{*)} Blast-Pro® fittings may only be used for tube cleaning operations inside the tube. They have not been designed for the use outside of tubes.